

<b>ELATION® PLATINUM SPOT 35 PRO™</b>				
<b>SKU# ESP863 - DMX Channel Values / Functions (41 DMX Channels) [ver 1.0]</b>				
Specifications are subject to change without any prior written notice.				
<b>MODE / CHANEL</b>			<b>VALUE</b>	<b>FUNCTION</b>
<b>STAND</b>	<b>BASIC</b>	<b>EXTEND</b>		
1	1	1		<b>PAN MOVEMENT [8 BIT]</b>
			0-255	PAN Movement
2		2		<b>PAN FINE MOVEMENT [16 BIT]</b>
			0-255	Fine Control of PAN Movement
3	2	3		<b>TILT MOVEMENT [8 BIT]</b>
			0-255	TILT Movement
4		4		<b>TILT MOVEMENT [16 BIT]</b>
			0-255	Fine Control of TILT Movement
5	3	5		<b>COLOR WHEEL</b>
			0-13	OPEN / WHITE
			14-27	RED
			28-41	BLUE
			42-55	GREEN
			56-69	YELLOW
			70-83	ORANGE
			84-97	PINK
			98-111	UV FILTER
			112-127	CTB
			128-189	Forward Color Effect from FAST to SLOW
			190-193	NO Rotation
			194-255	Backward Color Effect from SLOW to FAST
			0-255	FINE Adjustment of Color Wheel to Any Position
6	4	7		<b>CYAN</b>
			0-255	0-WHITE - 255-100% CYAN
		8		<b>CYAN FINE</b>
			0-255	FINE Adjustment of CYAN
7	5	9		<b>MAGENTA</b>
			0-255	0-WHITE - 255-100% MAGENTA
		10		<b>MAGENTA FINE</b>
			0-255	FINE Adjustment of MAGENTA
8	6	11		<b>YELLOW</b>
			0-255	0-WHITE - 255-100% YELLOW
		12		<b>YELLOW FINE</b>
			0-255	FINE Adjustment of YELLOW
9	7	13		<b>CTO COLOR</b>
			0-255	0-WHITE - 255-100% CTO
		14		<b>CTO COLOR FINE</b>
			0-255	FINE Adjustment of CTO
10	8	15		<b>ROTATING GOBOS, CONTINOUS ROTATION [GOBO WHEEL 1]</b>
			0-9	OPEN
			10-19	Rotating Gobo 1
			20-29	Rotating Gobo 2
			30-39	Rotating Gobo 3
			40-49	Rotating Gobo 4
			50-59	Rotating Gobo 5
			60-69	Rotating Gobo 6
			70-89	Gobo 1 Shake SLOW to FAST
			90-109	Gobo 2 Shake SLOW to FAST
			110-129	Gobo 3 Shake SLOW to FAST
			130-149	Gobo 4 Shake SLOW to FAST
			150-169	Gobo 5 Shake SLOW to FAST
			170-189	Gobo 6 Shake SLOW to FAST
			190-221	Gobo Wheel Rotation Forward from FAST to SLOW
			222-223	NO Rotation
			224-255	Gobo Wheel Rotation Backward from SLOW to FAST

**ELATION** | **PLATINUM SPOT 35 PRO™** | **dmx traits**

<b>ELATION® PLATINUM SPOT 35 PRO™</b>				
<b>SKU# ESP863 - DMX Channel Values / Functions (41 DMX Channels) [ver 1.0]</b>				
Specifications are subject to change without any prior written notice.				
<b>MODE / CHANEL</b>			<b>VALUE</b>	<b>FUNCTION</b>
<b>STAND</b>	<b>BASIC</b>	<b>EXTEND</b>		
11	9	16		<b>ROTATING GOBOS, INDEX ROTATION [GOBO WHEEL 1]</b>
			0-127	Gobo Indexing
			128-189	Forward Gobo Rotation from FAST TO SLOW
			190-193	NO Rotation
			194-255	Backward Gobo Rotation from SLOW to FAST
		17		<b>ROTATING GOBOS, FINE INDEX ROTATION [GOBO WHEEL 1]</b>
			0-255	Gobo Rotation FINE Indexing
12	10	18		<b>ROTATING GOBOS, CONTINUOUS ROTATION [GOBO WHEEL 2]</b>
			0-9	OPEN
			10-19	Rotating Gobo 1
			20-29	Rotating Gobo 2
			30-39	Rotating Gobo 3
			40-49	Rotating Gobo 4
			50-59	Rotating Gobo 5
			60-69	Rotating Gobo 6
			70-89	Gobo 1 Shake SLOW to FAST
			90-109	Gobo 2 Shake SLOW to FAST
			110-129	Gobo 3 Shake SLOW to FAST
			130-149	Gobo 4 Shake SLOW to FAST
			150-169	Gobo 5 Shake SLOW to FAST
			170-189	Gobo 6 Shake SLOW to FAST
			190-221	Gobo Wheel Rotation Forward from FAST to SLOW
			222-223	NO Rotation
			224-255	Gobo Wheel Rotation Backward from SLOW to FAST
13	11	19		<b>ROTATING GOBOS, INDEX ROTATION [GOBO WHEEL 2]</b>
			0-127	Gobo Indexing
			128-189	Forward Gobo Rotation from FAST TO SLOW
			190-193	NO Rotation
			194-255	Backwards gobo rotation from slow to fast
		20		<b>ROTATING GOBOS, FINE INDEX ROTATION [GOBO WHEEL 2]</b>
			0-255	Gobo Rotation FINE Indexing
14	12	21		<b>ROTATING PRISM, PRISM / GOBO MACROS</b>
			0-63	OPEN
			64-127	3-Facet Prism
			128-135	Gobo Macro 1
			136-143	Gobo Macro 2
			144-151	Gobo Macro 3
			152-159	Gobo Macro 4
			160-167	Gobo Macro 5
			168-175	Gobo Macro 6
			176-183	Gobo Macro 7
			184-191	Gobo Macro 8
			192-199	Gobo Macro 9
			200-207	Gobo Macro 10
			208-215	Gobo Macro 11
			216-223	Gobo Macro 12
			224-231	Gobo Macro 13
			232-239	Gobo Macro 14
240-247	Gobo Macro 15			
248-255	Gobo Macro 16			
15	13	22		<b>ROTATING PRISM, INDEX ROTATION</b>
			0-127	Prism Indexing
			128-189	Forward Prism Rotation from FAST to SLOW
			190-193	NO Rotation
			194-255	Backward Prism Rotation from SLOW to FAST

<b>ELATION® PLATINUM SPOT 35 PRO™</b>				
<b>SKU# ESP863 - DMX Channel Values / Functions (41 DMX Channels) [ver 1.0]</b>				
Specifications are subject to change without any prior written notice.				
<b>MODE / CHANEL</b>			<b>VALUE</b>	<b>FUNCTION</b>
<b>STAND</b>	<b>BASIC</b>	<b>EXTEND</b>		
		23		<b>ROTATING PRISM, FINE INDEX ROTATION</b>
			0-255	Prism FINE Indexing
16	14	24		<b>FOCUS</b>
			0-255	Continuous Adjustment from NEAR to FAR
		25		<b>FOCUS FINE</b>
			0-255	Continuous FINE Focus Adjustment
17	15	26		<b>MOTORIZED ZOOM</b>
			0-255	ZOOM Adjustment from SMALL to BIG
		27		<b>MOTORIZED ZOOM FINE</b>
			0-255	ZOOM FINE Adjustment
		28		<b>AUTO FOCUS</b>
			0-15	Auto Focus OFF
			16-31	5m
			32-47	7.5m
			48-255	10m
18	16			<b>AUTO FOCUS FINE</b>
		29	0-255	Continuous FINE Auto Focus Adjustment
		30		<b>SHUTTER, STROBE</b>
			0-31	Shutter CLOSED
			32-63	NO Function (Shutter OPEN)
			64-95	Strobe Effect SLOW to FAST
			96-127	NO function (Shutter OPEN)
			128-159	Pulse Effect In Sequences
			160-191	NO Function (Shutter OPEN)
			192-223	Random Strobe Effect SLOW to FAST
			224-255	NO Function (Shutter OPEN)
19	17	31		<b>DIMMER INTENSITY</b>
			0-255	Intensity 0 to 100%
		32		<b>DIMMER INTENSITY FINE</b>
			0-255	Dimmer Intensity FINE Adjustment
		33		<b>IRIS</b>
			0-191	MAX to MIN Diameter
			192-223	Pulse Opening FAST to SLOW
			224-255	Pulse Closing SLOW to FAST
20	18	34		<b>IRIS FINE</b>
			0-255	Iris FINE Adjustment
		35		<b>FROST</b>
			0-127	OPEN
			128-255	100% Frost
		36		<b>ANIMATION WHEEL</b>
			0-7	OPEN
			8-127	Forward Rotation from FAST to SLOW
			128-135	NO Rotation
			136-255	Backward Rotation from SLOW to FAST
21	19	37		<b>CMY &amp; COLOR WHEEL MACRO SPEED</b>
			0-255	MAX to MIN Speed

**ELATION® PLATINUM SPOT 35 PRO™**  
**SKU# ESP863 - DMX Channel Values / Functions (41 DMX Channels) [ver 1.0]**

Specifications are subject to change without any prior written notice.

MODE / CHANEL			VALUE	FUNCTION
STAND	BASIC	EXTEND		
26	24	38	<b>CMY &amp; COLOR WHEEL MACROS</b>	
			0-7	OFF
			8-15	Color Macro 1
			16-23	Color Macro 2
			24-31	Color Macro 3
			32-39	Color Macro 4
			40-47	Color Macro 5
			48-55	Color Macro 6
			56-63	Color Macro 7
			64-71	Color Macro 8
			72-79	Color Macro 9
			80-87	Color Macro 10
			88-95	Color Macro 11
			96-103	Color Macro 12
			104-111	Color Macro 13
			112-119	Color Macro 14
			120-127	Color Macro 15
			128-135	Color Macro 16
			136-143	Color Macro 17
			144-151	Color Macro 18
			152-159	Color Macro 19
			160-167	Color Macro 20
			168-175	Color Macro 21
			176-183	Color Macro 22
			184-191	Color Macro 23
			192-199	Color Macro 24
			200-207	Color Macro 25
			208-215	Color Macro 26
			216-223	Color Macro 27
			224-231	Color Macro 28
232-239	Color Macro 29			
240-247	Color Macro 30			
248-255	Random CMY			
27	25	39	<b>PAN / TILT MOVEMENT SPEED</b>	
			0-225	MAX to MIN Speed
			226-235	Blackout by Movement
			236-245	Blackout by ALL Wheel Changing
			246-255	NO Function
28	26	40	<b>PAN / TILT MOVEMENT MODE</b>	
			0-31	Quick
			32-63	Smooth
			64-255	NO Function

**ELATION® PLATINUM SPOT 35 PRO™**  
**SKU# ESP863 - DMX Channel Values / Functions (41 DMX Channels) [ver 1.0]**

Specifications are subject to change without any prior written notice.

MODE / CHANEL			VALUE	FUNCTION
STAND	BASIC	EXTEND		
29	27	41		<b>LAMP ON/OFF, RESET, INTERNAL PROGRAMS</b>
			0-19	Color & Gobo Change Normal
			20-29	Color Change to Any Position
			30-39	Color & Gobo Change to Any Position
			40-59	Lamp ON
			60-79	Lamp Switch OFF
			80-84	ALL Motor Reset
			85-87	SCAN Motor Reset
			88-90	COLORS Motor Reset
			91-93	GOBOS Motor Reset
			94-96	SHUTTER & DIMMER Motor Reset
			97-99	OTHER Motor Reset
			100-119	Internal Program 1 (Scene1-8)
			120-139	Internal Program 2 (Scene 9-16)
			140-159	Internal Program 3 (Scene 17-24)
			160-179	Internal Program 4 (Scene 25-32)
			180-199	Internal Program 5 (Scene 33-40)
			200-219	Internal Program 6 (Scene 41-48)
			220-239	Internal Program 7 (Scene 49-56)
			240-255	Music Control (Scene of Program 1)